# Traffic Controller



The traffic controller is a heavy duty in-ground "Directional Enforcer". It allows traffic in one direction only. It can be used as a free entrance or exit to your parking facility. It can be used to enforce one-way traffic in such drive-through areas as hotels, banks, commuter stations, etc. The Model 200-1 is 72" wide and includes twenty cut-steel blade teeth.


- Heavy-duty steel housing
- · Painted bright red for high visibility
- Flush mount installation
- Allows traffic in one direction
- Dimensions: 72" Long, 8-1/2" Width at top, 12-1/2" Width at bottom, 6" high
- Each spike is individually spring loaded
- Maximum speed over traffic controller is 5 MPH
- Shipping weight: 150 lbs.

Caution: Do not install traffic controllers in areas where vehicle speeds will exceed 5 MPH or where vehicles will cross the traffic controller at an angle other than 90°. Do not allow pedestrians in the traffic lane. Warning signs, speed bumps and/or stop signs are required to control traffic in traffic controller installations.



# **ENGINEERED PARKING SYSTEMS**


25010 AVENUE TIBBITTS, VALENCIA, CA 91355 PHONE (661) 294-0778 (800) EPSINFO (377-4636) FAX (661) 294-0674 www.epsinfo.com



### **MODEL 200-1 TRAFFIC CONTROLLER**

#### **INSTALLATION GUIDELINES**

- **1.** Install the traffic controller perpendicular to traffic flow. If vehicles cross the traffic controller at an angle other than 90°, the spikes may cause damage to sidew alls of tires.
- **2.** The maximum speed vehicles may cross the traffic controller is 5 MPH. Excessive wear of the spikes and top plate and/or broken springs will result from speeds greater than 5 MPH.
- **3.** The traffic controller should be installed in a location where the least amount of water will drain into the unit. Make sure there is adequate drainage under the unit.
- **4.** Make sure the unit is not installed on a slope where it is possible for vehicles to roll back onto the traffic controller.
- **5.** Keep pedestrians away from the traffic controller.
- **6.** Routine maintenance should be performed periodically to ensure that debris is not accumulating in the unit and that water is draining properly.
- **7.** Provide adequate night time illumination of the unit together with a clear sign warning of its presence.





# **ENGINEERED PARKING SYSTEMS**

25010 AVENUE TIBBITTS, VALENCIA, CA 91355 PHONE (661) 294-0778 (800) EPSINFO (377-4636) FAX (661) 294-0674 www.epsinfo.com